



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	631	Wrench	815	Drag control lever
40	Spool shaft spring	640	Drive shaft	873	Strike alert lever
43	Drive shaft washer	643	Pre-program key	907	Spool shaft
54	Spool cannulation	646	Pre-program key pin	908	Bearing cover
185	"E" washer	647	Set plate nail	910	Anti-reverse dog
187	"E" washer	649	Pre-program plate	911	Lever spring
202	Handle knob screw 1	655	Fixed plate	912	Sound bushing
207	Push slice screw	656	Spool spring washer	913	Cover
211	Set plate screws	659	Drag plate washer	914	Magnet
215	Cover screw	661	Handle washer	920	Sound gear
310	Slingshot meson	665	Big ring	922	Clamp
364	Handle knob screw 2	670	Close cover screws	924	Front drag plate
378	Ball bearing (S106)	671	Spool shaft screw	925	Rear drag plate
384	Ball bearing (S6700)	672	Fixed plate screws	926	Anti-reverse ratchet
389	Ball bearing (S695)	673	Screw for bearing cover	927	Alarm sound gear
392	Ball bearing (S105)	679	Washer 2	930	Side plate screws
395	One-way bearing	680	Drive shaft coat washer	931	Reel foot screws
400	Drive shaft coat	698	Spool ring	932	Sound bushing screw
401	"O" ring	714	T handle nail	935	Sound bushing slice
404	Friction spring	766	Drive shield	936	Bearing ring
406	Set plate	767	Lock set	937	Alarm spring
418	Sound coat	769	Down button	938	Drag control lever washer
420	Sound nail	772	Handle bolt	939	Slow down washer
425	Screw embedded clip	774	Drive gear-high speed	940	Drag plate
428	Sound nail spring	776	Handle arm	945	Small ring
453	Handle knob screw 3	777	Embedded clip	981	Drag plate undersleeve
547	Drag tension knob	778	Close cover	982	Handle knob (EVA)
564	Alarm pin	779	Loose sleeve screw	1048	High speed pinion gear
598	Handle bolt washer	781	Right plate	1144	Handle shaft coat
601	Washer 1	782	Frame		
627	Drag knob cover	783	Reel foot		
630	"O" ring	794	Spool		