



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	555	Embedded clip	679	Washer 3
40	Spool shaft spring	564	Alarm pin	680	Drive shaft coat washer
43	Drive shaft washer	598	Handle bolt washer	684	Drag plate
45	Reel foot cannulation	601	Washer 2	698	Spool ring
46	Reel foot screws	627	Drag knob cover	714	T handle nail
53	Spool shaft	630	"O" ring	715	Drag control lever
54	Spool cannulation	631	Wrench	767	Lock set
185	"E" washer	639	Rear drag plate	772	Handle bolt
187	"E" washer	640	Drive shaft	779	Loose sleeve screw
202	Handle knob screw 1	641	Bearing cover	798	Down button
207	Push slice screw	642	Front drag plate	800	Cover
211	Set plate screws	643	Pre-program key	803	Clamp
215	Cover screw	644	High speed pinion gear	804	Lever spring
246	Reel foot	646	Pre-program key pin	805	Slow down washer
310	Slingshot meson	647	Set plate nail	810	Spool
364	Handle knob screw	649	Pre-program plate	873	Strike alert lever
378	Ball bearing (S106)	651	Drag plate undersleeve	910	Anti-reverse dog
380	Ball bearing (S605)	655	Fixed plate	912	Sound bushing
384	Ball bearing (S6700)	656	Spool spring washer	914	Magnet
389	Ball bearing (S695)	659	Drag plate washer	932	Sound bushing screw
395	One-way bearing	660	Bearing ring	935	Sound bushing slice
400	Drive shaft coat	661	Handle washer	937	Alarm spring
401	"O" ring	662	Anti-reverse ratchet	946	Sound gear
404	Friction spring	664	Spool spring washer	952	Drive shield
406	Set plate	665	Big ring	953	Close cover
418	Sound coat	666	Small ring	954	Handle arm
420	Sound nail	669	Side plate screws	955	Right plate
425	Screw embedded clip	670	Close cover screws	956	Frame
428	Sound nail spring	671	Spool shaft screw	982	Handle knob (EVA)
453	Handle knob screw	672	Fixed plate screws	984	Drive gear-high speed
539	Alarm sound gear	673	Screw for bearing cover	1144	Handle shaft coat
547	Drag tension knob	677	Drag control lever washer		