



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	451	Handle nut washer	733	Clutch release yoke	769	Down button
211	Set plate screws	457	Clutch dog	734	Clutch release bar	779	Loose sleeve screw
215	Cover screw	460	Drive shaft shield	736	Soundspring plate	780	Handle knob (EVA)
302	Star drag washer	462	Clutch spring	737	Decorative cover	873	Strike alert lever
384	Ball bearing (S6700)	463	Cast controlspring	738	Close cover	912	Bushing
388	Ball bearing (S85)	464	Click spring A	739	Handle arm	914	Magnet
389	Ball bearing (S695)	465	Bearingspring	740	Drive shaft	920	Sound gear
391	One-waybearing	467	Yoke plate	741	Drive gear	921	T handle nail
392	Ball bearing (S105)	468	Yoke	743	Drive shaftbushing	922	Cramp
393	Ball bearing (S128)	469	Clutchskid	744	Anti-reverseratchet	927	Alarm sound gear
394	Ball bearing (S126)	471	Clutchlever bracket	745	Drive shaft washer	935	Clip
410	Cast control screw	473	Drag washer A	746	Right plate	936	Bearing ring
411	Cast control bracket	474	Drag washer B	747	Frame	937	Alarm spring
412	Yoke ratchet	564	Alarm pin	748	Spool	939	Slow down washer
435	Clutch lever screw	601	Washer 1	749	Transitional board	943	Handle knob screw
437	One-waybearing tube	631	Wrench	750	Lever wind washer	944	Handle lock ring
438	Anti-reversenail	668	Side plate screws	751	Pinion gear	988	Ball bearing (S74)
440	Spool shaft nail	670	Close cover screws	752	Tension knob	1021	Yoke spring
443	Eared washer	679	Washer 2	753	Star drag knob	1320	Reel foot spacer
444	Key washer A	687	Aprons	754	Fixed screw	1321	Reel foot
445	Key washer B	726	Release bar	759	Thimble	1322	Reel foot screws
446	Anti-reverse dog	727	Side part for Release bar	760	Spool shaft		
447	Anti-reverse plate	728	Fixing lever	761	Thimble spring		
448	Click bracket	730	Knob cover	767	Lock set		
449	Spring washer	731	Handle bolt	768	Handle shaft coat		