



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
8	Pre-program key	655	Fixed plate	925	Rear drag plate
11	Friction spring	656	Spool spring washer	930	Side plate screws
21	Drag tension knob	659	Drag plate washer	931	Reel foot screws
40	Spool shaft spring	661	Handle washer	936	Bearing ring
43	Drive shaft washer	665	Big ring	937	Alarm spring
185	"E" washer	670	Close cover screws	938	Drag control lever washer
187	"E" washer	671	Spool shaft screw	940	Drag plate
191	Set plate	672	Fixed plate screws	941	Anti-reverse ratchet
207	Push slice screw	673	Screw for bearing cover	943	Handle knob screw
211	Set plate screws	679	Washer 2	944	Handle lock ring
215	Cover screw	680	Drive shaft coat washer	945	Small ring
384	Ball bearing (S6700)	698	Spool ring	954	Handle arm
388	Ball bearing (S85)	766	Drive shield	981	Drag plate undersleeve
389	Ball bearing (S695)	767	Lock set	1046	Spool shaft
392	Ball bearing (S105)	768	Handle shaft coat	1047	Spool cannulation
395	One-way bearing	770	Handle fixing cover	1048	High speed pinion gear
400	Drive shaft coat	772	Handle bolt	1051	Spool
401	"O" ring	774	Drive gear-high speed	1053	Pre-program plate
418	Sound coat	779	Loose sleeve screw	1054	Frame
420	Sound nail	780	Handle knob (EVA)	1055	Cover
425	Screw embedded clip	787	Embedded clip	1056	Sound gear
428	Sound nail spring	788	Close cover	1057	Alarm sound gear
564	Alarm pin	789	Right plate	1058	Drag control lever
598	Handle bolt washer	795	Wrench	1320	Reel foot spacer
601	Washer 1	873	Strike alert lever	1321	Reel foot
627	Drag knob cover	908	Bearing cover	1322	Reel foot screws
630	"O" ring	910	Anti-reverse dog		
640	Drive shaft	911	Lever spring		
646	Pre-program key pin	921	T handle nail		
647	Set plate nail	924	Front drag plate		