



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	425	Screw embedded clip	681	Alert ratchet
14	Handle shaft coat	426	Screw for bearing cover	682	Drive shaft coat washer
17	Washer 2	427	Stopping stock spring	703	Spool ring
178	Set plate nail	428	Sound nail spring	828	Drive gear-high speed
185	"E" washer	429	Bearing ring	829	Right plate
195	Rod clamp	430	Drag control lever washer	830	Frame
202	Handle knob screw 1	431	"O" ring	831	Drive shaft coat
207	Push slice screw	503	Fixed screws	832	Drive shield
211	Set plate screws	506	Reel foot	834	Embedded clip
214	Alert ratchet screws	546	Drive shaft washer	835	Rear drag plate
215	Cover screw	554	Handle arm	860	Drag tension knob
379	Ball bearing (S117)	581	T handle nail	862	Spool shaft
381	Ball bearing (S606)	598	Handle bolt washer	863	High speed pinion gear
384	Ball bearing (S6700)	601	Washer 3	870	Spool cannulation
390	Ball bearing (S696)	602	Handle knob screw 2	873	Strike alert lever
395	One-way bearing	604	Spool shaft spring	878	Anti-reverse ratchet
396	Handle washer	629	Handle knob	880	Front drag plate
397	Drive shaft	630	"O" ring	886	Reel foot screws
398	Pre-program plate	631	Wrench	890	Cover
406	Set plate	650	Handle bolt	892	Drag plate
416	"E" washer	655	Fixed plate	895	Drag control lever
417	Drag knob cover	657	Alarm sound gear	896	Spool
418	Sound coat	665	Big ring	897	Drag plate undersleeve
419	Pre-program key pin	666	Small ring	898	Spool spring washer
420	Sound nail	668	Side plate screws	901	Pre-program key
421	Bearing cover	670	Close cover screws	909	Close cover
422	Spool spring washer	672	Fixed plate screws	910	Anti-reverse dog
423	Drag plate washer	674	Anti-loose screw		
424	Spool shaft screw	679	Washer 1		