



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	422	Spool spring washer	829	Right plate
14	Handle shaft coat	423	Drag plate washer	831	Drive shaft coat
17	Washer 2	424	Spool shaft screw	832	Drive shield
39	Button screw	425	Screw embedded clip	834	Embedded clip
41	Reel foot cannulation 1	426	Screw for bearing cover	835	Rear drag plate
42	Reel foot	427	Stopping stock spring	859	Button lever knob
44	Fixed screws	428	Sound nail spring	860	Drag tension knob
45	Reel foot cannulation 2	429	Bearing ring	863	High speed pinion gear
46	Reel foot screws	430	Drag control lever washer	864	Low speed pinion gear
48	Rod clamp	431	"O" ring	865	Drive gear-high speed
165	Fixed nuts	546	Drive shaft washer	866	Drive gear-low speed
178	Set plate nail	574	Button basement	867	Drive shaft
185	"E" washer	581	T handle nail	868	Push button shaft
202	Handle knob screw 1	584	Push nail	869	Slide pole
207	Push slice screw	593	Push slice	871	Variable-speed pin
211	Set plate screws	594	Stopping slice	872	Handle bolt
214	Alert ratchet screws	598	Handle bolt washer	878	Anti-reverse ratchet
215	Cover screw	601	Washer 3	880	Front drag plate
375	Spool shaft	602	Handle knob screw 2	884	"C" washer
376	Spool cannulation	603	Push spring	885	Handle washer
379	Ball bearing (S117)	604	Spool shaft spring	887	Drive shaft spring
381	Ball bearing (S606)	629	Handle knob	888	Shaft insert spring
384	Ball bearing (S6700)	630	"O" ring	889	Drive shaft coat washer
386	Spool	631	Wrench	890	Cover
387	Frame	657	Alarm sound gear	891	Variable-speed washer
390	Ball bearing (S696)	665	Big ring	892	Drag plate
406	Set plate	666	Small ring	895	Drag control lever
415	Strike alert lever	667	Anti-reverse dog	897	Drag plate undersleeve
416	"E" washer	668	Side plate screws	898	Spool spring washer
417	Drag knob cover	670	Close cover screws	900	Pre-program plate
418	Sound coat	679	Washer 1	901	Pre-program key
419	Pre-program key pin	681	Alert ratchet	909	Close cover
420	Sound nail	697	Handle arm		
421	Bearing cover	703	Spool ring		