



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	503	Fixed screws	860	Drag tension knob
14	Handle shaft coat	506	Reel foot	862	Spool shaft
17	Washer 2	546	Drive shaft washer	863	High speed pinion gear
39	Button screw	574	Button basement	864	Low speed pinion gear
178	Set plate nail	581	T handle nail	865	Drive gear-high speed
185	"E" washer	584	Push nail	866	Drive gear-low speed
195	Rod clamp	593	Push slice	867	Drive shaft
202	Handle knob screw 1	594	Stopping slice	868	Push button shaft
207	Push slice screw	598	Handle bolt washer	869	Slide pole
211	Set plate screws	601	Washer 3	870	Spool cannulation
214	Alert ratchet screws	602	Handle knob screw 2	871	Variable-speed pin
215	Cover screw	603	Push spring	872	Handle bolt
379	Ball bearing (S117)	604	Spool shaft spring	873	Strike alert lever
381	Ball bearing (S606)	629	Handle knob	878	Anti-reverse ratchet
384	Ball bearing (S6700)	630	"O" ring	880	Front drag plate
390	Ball bearing (S696)	631	Wrench	884	"C" washer
406	Set plate	657	Alarm sound gear	885	Handle washer
416	"E" washer	665	Big ring	886	Reel foot screws
417	Drag knob cover	666	Small ring	887	Drive shaft spring
418	Sound coat	667	Anti-reverse dog	888	Shaft insert spring
419	Pre-program key pin	668	Side plate screws	889	Drive shaft coat washer
420	Sound nail	670	Close cover screws	890	Cover
421	Bearing cover	679	Washer 1	891	Variable-speed washer
422	Spool spring washer	681	Alert ratchet	892	Drag plate
423	Drag plate washer	697	Handle arm	895	Drag control lever
424	Spool shaft screw	703	Spool ring	896	Spool
425	Screw embedded clip	829	Right plate	897	Drag plate undersleeve
426	Screw for bearing cover	830	Frame	898	Spool spring washer
427	Stopping slock spring	831	Drive shaft coat	900	Pre-program plate
428	Sound nail spring	832	Drive shield	901	Pre-program key
429	Bearing ring	834	Embedded clip	909	Close cover
430	Drag control lever washer	835	Rear drag plate		
431	"O" ring	859	Button lever knob		